



Expolux

8 990 7.5 .0.
8 990 7.6 .0.
8 990 7.5 .1.
8 990 7.6 .1.

Schutzart - Protection IP 65
Schutzklasse - Safety Class I

$t_a 25^\circ\text{C}$



MONTAGE ANLEITUNG Mounting instructions



WILLY MEYER & SOHN GMBH & CO.KG
LICHTTECHNISCHE SPEZIALFABRIK
Stemmessiepen Weg 5 • D-58675 Hemer

LED-Leuchte mit 18 Watt.

MONTAGEHINWEISE

Anschluß der Leuchte nach VDE 0100.
Scheinwerfer für ungeschützte Anlagen.
Leuchte ist geeignet für die Montage auf
normal entflammaren Baustoffen.


Vor dem Öffnen der Leuchte Netzspannung
trennen !

Zur Verdrahtung (Aufputz) der Leuchte
vorgeformte Öffnung an der Wandplatte
ausbrechen (A) und Bruchrand entgraten.
Wandplatte des Auslegers mit beiliegendem
Befestigungsmaterial befestigen.
Zur Vereinfachung der Montage kann der
Leuchtenkopf vom Ausleger genommen werden.
Netzanschlußleitung 10 cm abmanteln und
durch die Kabelverschraubung führen,
dabei passenden Dichtungssatz (Lieferumfang)
wählen.

Polycarbonatabdeckung aufsetzen und
Schrauben gleichmäßig über Kreuz anziehen:

Maximales Drehmoment: 2 Nm

Leuchte ausrichten und Schrauben am Wandarm
anziehen. Zusätzliche Gewindestifte (B) zur
Sicherung der eingestellten Ausrichtung.




Die Leuchte darf nur mit ihren vollständigen
Schutzabdeckungen betrieben werden.

Leuchte	Gewicht	Windangriffsfläche
8 990 7.5 ...	2,1 kg	0,04 m ²
8 990 7.6 ...	2,1 kg	0,04 m ²



Die in dieser Leuchte eingebaute
Lichtquelle darf nur durch den
Hersteller oder seinen Kundendienst oder eine
ähnlich qualifizierte Person ersetzt werden.

In Strahlrichtung den Mindestabstand zu
angestrahlten Flächen einhalten !



min 0,2 m

LED outdoor luminaire with 18 Watts.

MOUNTING INSTRUCTIONS

Connection of light fitting in compliance with the
prevailing regulations in your country.

Luminaire for non-protected outdoor installation.
Luminaire is suitable for mounting on
normal inflammable surfaces.

Disconnect from power supply before opening
light fitting.


For wiring (surface mounted cable) break out the
pre-formed opening in the wall plate (A) and file
down any burrs. Wall plate must be mounted to
the surface using the enclosed assembly kit.

To simplify the assembly the light fitting can be
detached from the wall arm. Strip the sheathing
off the last 10 cm of the cable and insert through
the cable entry, making sure that the correct cable
entry gasket is used for the diameter of the cable
(gaskets are supplied with luminaire).

Replace and screw down polycarbonate cover
evenly by tightening screws crosswise:

Maximum torque: 2 Nm

Adjust luminaire and tighten screws at the wall
arm. Additional set screws (B) to secure the
adjusted tilt angle.




Luminaire may be operated only if all protective
covers are in place.

Part number	Weight	Projected area
8 990 7.5 ...	2.1 kg	0.04 m ²
8 990 7.6 ...	2.1 kg	0.04 m ²



The light source contained in this
luminaire shall only be replaced by
the manufacturer or his service agent or a similar
qualified person.

Ensure that the minimum distance between
luminaire and illuminated surface is observed.



min 0,2 m

Maximale Belastung von Leitungsschutzautomaten / Maximum loading of automatic circuit breakers

I_{peak} 5 A

Sicherungsautomat / automatic circuit breaker type:

Anzahl Leuchten / number of luminaires:

C16	B10	B16	B20
85	31	50	62

